



# Standard Video Parental Controls

## Setting up your PIN

- Press “CBL” button
- Press “MENU” button
- Select  “TV Guide Main Menu”
- Select “Setup”
- Select “PINs Setup”
- Scroll down to “Enter a new Purchase PIN” and enter the 4-digit PIN of your choice.
- You may be asked to confirm the PIN.
- If it says what you entered does not match your PIN and you don’t know what it is, call RTC at 1.888.862.3115 to have it re-set.
- Press “EXIT”

## Setting Up / Altering Parental Controls

- Press “CBL” button
- Press “MENU” button
- Select  “TV Guide Main Menu”
- Select “Setup”
- Select “Locks Set-up”
- Enter your 4-digit PIN. (If you don’t know your PIN, call RTC at 1.888.862.3115 to have it re-set.)

### To set controls based on the program’s rating...

- Scroll down to TV Ratings Locks and Movie Rating locks. Use the right and left arrows to find the rating you would like to lock and press the “OK/SEL” button for each rating you would like to block.

### To set controls based on the channel number...

- Scroll down to Channel Locks. Use the right and left arrows to find the channel you would like to lock and press the “OK/SEL” button for each channel you would like to block.

### To bypass or clear locks...

- Scroll down to Master Locks and press the “OK/SEL” button. Use the right and left arrows to select your options. Use the “LAST” button to go back to the previous screen.

### To hide adult titles in the channel guide....

- Scroll down to Adult Titles and use the right and left arrows to select the option of your choice.

### To go back to watching TV...

- Press “EXIT” button.



1.888.862.3115  
www.RTC.coop